

驾驶舱准备	
ADIRS.....	NAV
驾驶舱准备.....	完成(两人)
起落架销&护盖.....	移除
燃油量.....	___吨
起飞数据.....	___调定
气压基准.....	___调定(两人)
航电面板.....	交叉检查(两人)
HUD.....	放出/ON
安全带.....	ON

起动前	
便携式电子设备.....	飞行模式(两人)
舱门.....	关闭
停留刹车.....	按需
推力手柄.....	慢车
监视系统默认设置.....	选择(两人)
防撞灯.....	ON

起动后	
防冰.....	按需
ECAM 状态.....	检查
俯仰配平.....	___调定
方向舵配平.....	零位
飞行操纵.....	检查(两人)
飞行仪表.....	检查(两人)
简令.....	完成
襟翼调定.....	形态___(两人)
起飞速度 & 推力.....	___(两人)
应答机.....	设置
气象雷达.....	ON
ECAM 备忘.....	起飞无蓝字
SIGNS ON CABIN READY SPLRS ARM FLAPS T/O AUTO BRK RTO T/O CONFIG NORM	

起飞前	
起飞跑道 & SID.....	证实(两人)
FCU 高度.....	设置
空调组件.....	按需
刹车风扇.....	OFF

起飞后	
起落架.....	UP
襟翼.....	收上
空调组件.....	按需
气压基准.....	___调定(两人)
HUD.....	收上/ON

巡航	
OIS 航路备降场.....	高亮
航路紧急程序.....	按顺序回顾

进近	
简令.....	完成
ECAM 状态.....	检查
气压基准.....	___调定(两人)
决断高/最低高度.....	___调定(两人)
HUD.....	放出/ON
安全带指示灯.....	ON

着陆前	
客舱机组.....	通知
A/THR.....	SPEED/OFF
道面条件.....	___设置
自动刹车.....	按需
复飞高度.....	___调定
ECAM 备忘.....	着陆无蓝字
SIGNS ON CABIN READY L/G GEAR SPLRS ARM FLAPS SET	

着陆后	
扰流板.....	解除预位
襟翼.....	按需/收回
APU.....	起动

停机	
发动机.....	OFF
燃油泵.....	OFF
APU 引气.....	ON
安全带指示灯.....	OFF
外部灯光.....	按需
停留刹车和轮挡.....	按需
应答机.....	STBY
CLOSE FLIGHT 选项.....	选择(两人)
HUD.....	收上/ON

离机	
ADIRS.....	OFF
机组供氧.....	OFF
APU 引气.....	OFF
紧急出口灯光.....	OFF
SIGNS.....	OFF
EFB.....	OFF
APU.....	OFF
电频.....	OFF

驾驶舱准备

ADIRS.....NAV
 COCKPIT PREP.....COMPLETE (BOTH)
 GEAR PINS & COVERS.....REMOVED
 FUEL QUANTITY.....KG/LB
 T/O DATA.....SET
 BARO REF.....SET (BOTH)
 AVIONICS.....CROSS CHECK (BOTH)
 HUD.....ON
 SEATBELTS.....ON

起动前

MOBILE DEVICE.....AIRPLANE MODE (BOTH)
 DOORS.....CLOSE
 PARKING BRK.....AS REQUIRED
 THR LEVERS.....IDLE
 SURVS.....SELECT (BOTH)
 BEACON.....ON

起动后

ANTI ICE.....AS REQUIRED
 ECAM STATUS.....CHECKED
 PITCH TRIM.....SET
 RUDDER TRIM.....ZERO
 FLIGHT CONTROLS.....CHECKED (BOTH)
 FLT INST.....CHECKED (BOTH)
 BRIEFING.....COMPLETE
 FLAP SETTING.....CONF ____ (BOTH)
 V1.VR.V2/FLEX TEMP.....(BOTH)
 TRANSPONDER.....SET
 WX RADAR.....ON
 ECAM MEMO.....T/O NO BLUE
 SIGNS ON
 CABIN READY
 SPLRS ARM
 FLAPS T/O
 AUTO BRK RTO
 T/O CONFIG NORM

起飞前

TO RWY & SID.....VERIFY(BOTH)
 FCU ATL.....SET
 PACKS.....AS REQUIRED
 BRK FAN.....OFF

起飞后

LDG GEAR.....UP
 FLAPS.....UP
 PACKS.....AS REQUIRED
 BARO REF.....SET (BOTH)
 HUD.....ON

巡航

OIS ROUTE ATLNHIGHLIGHT
 EMR PROCEDURE.....REVIEW AS PREV BRF.

进近

BRIEFING.....COMPLETE
 ECAM STATUS.....CHECKED
 BARO REF.....SET (BOTH)
 MINIMUMS.....SET (BOTH)
 HUD.....ON
 SEATBELTS SIGN.....ON

着陆前

CABIN.....READY
 A/THR.....SPEED/OFF
 RWY CONTAMINATION.....SET
 AUTO BRK.....AS REQUIRED
 MISS ARPOACH ATL.....SET
 ECAM MEMO.....LDG NO BLUE
 SIGNS ON
 CABIN READY
 L/G GEAR
 SPLRS ARM
 FLAPS SET

着陆后	
SPLS.....	DISARM
FLAPS.....	AS REQUIRED
APU.....	START

停机	
ENGINES.....	OFF
FUEL PUMPS.....	OFF
APU BLEED.....	ON
SEATBELTS SIGN.....	OFF
EXIT LIGHTS.....	AS REQUIRED
PARKING BRK & CHOCKS.....	AS REQUIRED
TRANSPONDER.....	STBY
CLOSE FLIGHT OPT.....	SELECT (BOTH)
HUD.....	ON

离机	
ADIRS.....	OFF
OXYGEN.....	OFF
APU BLEED.....	OFF
EMER EXIT LIGHTS.....	OFF
SIGNS.....	OFF
EFB.....	OFF
APU.....	OFF
BAT.....	OFF